


Let  $\vec{Q}$  denote the heat flow vector


High  
Temperature



$$|\vec{Q}| = \text{cal/sec/m}^2$$


Low  
Temperature

Let  $\vec{Q}$  denote the heat flow vector




$\vec{Q} \cdot \vec{n} dS$  is cal/sec of heat flowing through a section of surface of area  $dS$

Let  $\vec{Q}$  denote the heat flow vector



$H = \iint_S \vec{Q} \cdot \vec{n} dS$  is cal/sec of heat flowing through the entire surface  $S$

Let  $u = u(x, y, z)$  be the temperature at point  $(x, y, z)$ . The temperature gradient points in the direction of increasing temperature



Fourier's Law:

$$\vec{Q} = -k\nabla u$$

$$H = \iint_S \vec{\mathbf{Q}} \bullet \vec{\mathbf{n}} \, dS = -k \iint_S \nabla u \bullet \vec{\mathbf{n}} \, dS$$

In an interior section of volume  $\Delta V$ , the heat gain is proportional to the mass and the change in temperature

$$\text{Heat Gain} = c \cdot \Delta u \cdot \rho \Delta V$$

$$\text{Heat Loss} = -c\rho\Delta u\Delta V$$



$$\text{Rate of Heat Loss} = -c\rho \frac{\Delta u}{\Delta t} \Delta V \approx -c\rho \frac{\partial u}{\partial t} \Delta V$$

This is the rate that the heat is leaving one small interior section

Total rate that the heat is leaving the solid is:

$$\iiint_V -c\rho \frac{\partial u}{\partial t} dV$$

$$-k \iint_S \nabla u \bullet \vec{\mathbf{n}} \, dS = \iiint_V -c\rho \frac{\partial u}{\partial t} \, dV$$

$$-k \iint_S \nabla u \bullet \vec{\mathbf{n}} \, dS = \iiint_V -c\rho \frac{\partial u}{\partial t} \, dV$$

$$-k \iiint_V \nabla \bullet (\nabla u) \, dV = \iiint_V -c\rho \frac{\partial u}{\partial t} \, dv$$

$$\iiint_V \left( k \nabla^2 u - c\rho \frac{\partial u}{\partial t} \right) \, dV = 0$$

$$k \nabla^2 u - c\rho \frac{\partial u}{\partial t} = 0$$

$$\frac{\partial u}{\partial t} = \frac{k}{c\rho} \nabla^2 u$$

$$\frac{\partial u}{\partial t} = \frac{k}{c\rho} \nabla^2 u$$

Let  $\alpha = \sqrt{\frac{k}{c\rho}}$

$$\frac{\partial u}{\partial t} = \alpha^2 \nabla^2 u$$

## The Heat Equation

$$\frac{\partial u}{\partial t} = \alpha^2 \left( \frac{\partial^2 u}{\partial x^2} + \frac{\partial^2 u}{\partial y^2} + \frac{\partial^2 u}{\partial z^2} \right)$$

In the special case where  $u = u(x, t)$ , the heat equation becomes:

$$\frac{\partial u}{\partial t} = \alpha^2 \frac{\partial^2 u}{\partial x^2}$$